

# How to Jump a Car

## Begin with Both Cars Off

1. Connect red to dead +
2. Connect red to donor +
3. Connect black to donor -
4. Connect black to bare metal
5. Start donor car
6. Start dead car
7. Disconnect 4 - 3 - 2 - 1

